GROUP-16




ELECTRICAL SYSTEM

GENEDA.

OCIVERAL """"""""""""""""""""""""""""""""""""	16-2
STARTER MOTOR	20
EIS DISTRIBUTOR - CEI TYPE	28
IGNITION COIL	
SPARK PLUG	
ALTERNATOR	
BATTERY	
FUSES	
IGNITION SWITCH	
METERS AND GAUGES	45
INDICATORS AND WARNING LAMPS	52
LIGHTING SYSTEM	61
WINDSHIELD WIPERS AND WASHER	75
HORN	83
CLOCK	'86
RADIO AND CAR STEREO	87
REAR WINDOW DEFOGGER	91
ELECTRICAL RADIATOR FAN	95 ~\

MARIZAM B. ABDOL RAM

EIS DISTRIBUTOR — CEI TYPE



REMOVAL

Disconnect battery ground cable.

Disconnect distributor wiring from terminals of

Disconnect spark plug cables and secondary cable from distributor

Disconnect vacuum hose from vacuum


Remove distributor mounting nut, then remove distributor assembly from cylinder head.

DISASSEMBLY


Remove retaining clips, then cap and seal ring. Pull off rotor from rotor shaft.

Remove two vacuum controller attaching screws.

Remove link of controller from pin on igniter base, then remove vacuum controller.





Remove lead wire (black).



Remove signal rotor shaft tightening screw and two igniter base retaining screws.
Remove signal rotor shaft and igniter base


assembly.






EIS DISTRIBUTOR — CEI TYPE

Place igniter base on soft base (wooden block) and lightly tap rotor shaft to remove it from signal rotor.



Remove two spring retainers with pliers and then remove two governor springs.
Remove two governor weights.




Mark location of drive gear on distributor shaft.

Place drive gear on soft base (wooden block) so that roll pin can be removed.

Using a pin punch, remove roll pin.


Remove drive gear and washer.

Remove distributor shaft from housing.




REASSEMBLY


Reassemble distributor in reverse order of disassembly, with following exception.
Install drive gear into distributor shaft at previously marked location. Then install new roll pin.




EIS DISTRIBUTOR — CEI TYPE




Install igniter base in housing with its projection (A) fitted in groove (B).



Install signal rotor on rotor shaft while fitting dowel pin of signal rotor in groove of shaft.



Adjust air gap between signal rotor and pick-up of igniter.







INSTALLATION

Turn crankshaft until piston in No. 1 cylinder is at top dead center on compression stroke.

Align mating mark on distributor housing with that (punch mark) on distributor driven gear.





EIS DISTRIBUTOR - CEI TYPE / IGNITION'COIL

install distributor to cylinder nead while aligning mating mark on distributor attaching flange with center of distributor installing stud and tighten nuts.


Connect spark plug cables and secondary cable to distributor.

Connect distributor wiring to ignition coil

Connect battery ground cable

Connect vacuum hose to vacuum controller nippie.

Adjust ignition timing




IGNITION COIL

INSPECTION

Using a circuit tester, measure resistance. A resistor with open- or short-circuited coil should be replaced.

Check resin portion for cracks. If there are cracks, replace.

Check for fluid loil) leaks If there are leaks, replace.




SPARK PLUG



1.5

REMOVAL

When spark plug cable is pulled out, be sure to hold cable cap. If spark plug, is removed by holding cable alone, open circuit might result.




INSPECTION

Perform following checks on spark plugs and replace if defective.

- (1) Broken insulator
- (2) Worn electrode
- (3) Deposited carbon

 Use a plug cleaner or wire brush for cleaning.

 Clean porcelain insulator above shell as well.
- (4) Damaged or broken gasket
- (5) Burnt condition of porcelain insulator at spark gap
 - Olf black carbon deposit is evident, probable cause is too rich a fuel mixture or extremely low air intake. Misfiring due to excessive spark gap is also suspected.
 - Olf insulator is burnt white, too lean a fuel mixture, excessively advanced ignition timing, improperly tightened plug, etc. are suspected.







INSTALLATION


Check plug gap. If necessary, adjust to specification.

Tighten spark plug to specified torque. If it is overtorqued, damage to threaded portion of cylinder head might result.





COMPONENTS



1EL093

REMOVAL

Set ignition switch to "OFF" and disconnect ground cable from battery.

Disconnect wire from "B" terminal.

Disconnect wiring connector from alternator.


Loosen drive belt.

Remove alternator brace bolt and support bolt, then remove alternator.

DISASSEMBLY

Remove three through bolts.

Rear bracket may be hard to remove because a ring is used to lock outer race of rear bearing. To facilitate removal of rear bracket, heat just bearing box section with a 200 watt soldering iron. Do not use a heat gun, as it can damage diode assembly.





Insert a flat-tip screwdriver between front bracket and stator core, and pry downward.

Caution

Do not insert screwdriver too deep as there is danger of damage to stator coil.

Clamp rotor in a vise with pulley side up (to protect rotor from vise jaws).

Remove pulley nut, then spring washer, pulley, fan and collar.


Remove front bracket and two seals.

Remove rotor from vise.

Remove nut from "B" terminal and remove washer and condenser.

Remove brush holder screw and rectifier screws.

Remove stator assembly from rear bracket.



CAHIM

If stator is to be removed, unsolder three stator leads to disconnect them from main diodes on rectifier.

Caution

Finish soldering or unsoldering in as short a time as possible. Diode will be damaged if heat of soldering iron is transmitted to diode for long time.

Use care not to exert undue force to leads of diodes.


When separating rectifier from brush holder, unsolder two plates to separate them from rectifier.


INSPECTION


Rotor

Check rotor coil for continuity. Check to ensure that there is continuity between slip rings. Resistance of rotor should be 3 to 4 ohm/20°C.


If resistance is too small, it means that there is a short circuit. If there is no continuity or if there is a short circuit, replace rotor assembly.








Check rotor coil for grounding. Check to ensure that there is no continuity between slip ring and core. If there is continuity, replace rotor assembly.




Stator

Make continuity test on stator coil. Check to ensure that there is continuity between coil leads

If there is no continuity, replace stator assembly.





Check coil for grounding. Check to ensure that there is no continuity between coil and core. If there is continuity, replace stator assembly.



Rectifier


Check six main diodes and three auxiliary diodes for continuity by connecting a circuit tester to both ends of each diode. If there is continuity or no continuity in both directions, diode is defective and rectifier assembly must be replaced.






BRUSH REPLACEMENT


Brush worn down to wear limit line should be replaced.



Unsolder pigtail, then brush and spring will come



To install a new brush, solder pigtail so that brush will enter holder about 5 mm.






REASSEMBLY

Reassemble alternator in reverse order of disassembly, with following exception.

Before rotor is attached to rear bracket, insert a wire through small hole made in rear bracket to lift a brush

Alter rotor has been installed, remove wire.




INSTALLATION

Instali alternator in reverse order of removal, with following exception.

Push alternator toward front of engine and check for clearance "A" between alternator leg and front case or timing chain case. If clearance is more than 0.2 mm, insert spacers (0.198 mm thick) as required

If support bolt is tightened without reducing clearance "A", alternator leg might be broken Adjust drive belt tension.



BATTERY



SPECIFICATIONS

Type	
Voitage V	
Capacity (20HR) Ah	N40
Electrolyte specific gravity at 20°C	. 12
NOTE:	40
NOTE If the specific gravity of the battery electronic	1.260
If the specific gravity of the battery electrolyte falls 0.06. TROUBLESHOOTING	or more, recharge the battery

TROUBLESHOOTING

Overcharged battery Symptoms The case temperature becomes too high. The electrolyte evaporates quickly A strange odor is emitted. is the specific gravity of the electrolyte 1 260 at 20°C when Add distilled water and adjust No the electrolyte level is at the specific gravity of the electrolyte. the upper position? Yes . 1 Start the engine and cun the alternator at about 5,000 rimin engine speed about 2,500 CONT. Caution Turn off all lights and electrical accessories to take the load off the battery. Do not run the engine at high speed, and do not abruptly increase the engine speed. Do not disconnect the cables from the battery terminals. The specific gravity of the electrolyte will drop 0.0007 for each 1°C that the temperature of electrolyte rises. The voltage of the alternator "L" terminal will drop 0.1V for each 10°C that the atmospheric temperature rises. is the voltage between the No IC regulator malfunction Replace the regulator assembly alternator "B" terminal and earth 144 = 05V at 20°C? Yes

Alternator malfunction

terminal.

Field-coil is earthed


Metallic foreign matter

caught on the brush holder

16 - 39


Correct or replace the alternator

Test the battery performance




BATTERY

Undercharged battery (The voltage between the battery terminals is less than 12V)



BATTERY



NOTES CONCERNING THE CHARGING

The alternator is equipped with a built-in IC voltage regulator.

Be careful of the following items during inspection or service of the electrical system:

- (1) Do not connect the battery in reverse polarity.
- (2) Do not disconnect the cables from the battery terminals while the engine is running.
- (3) Do not earth the "L" terminal.
- (4) Do not allow either the "L" terminal or "R" terminal to short circuit.
- (5) If using a steam cleaner, do not aim it directly at the alternator.



For normal charging, charge the battery at a current 1/10 of the battery capacity.

For quick recharging (boosting), the maximum current should be equal to the battery capacity indicated in amperes (A).

Adjust the charging current so that the temperature of the electrolyte during charging does not exceed 45°C.

When connecting the cables to the battery terminals, begin with the positive (+) terminal. When disconnecting the cables, begin with the negative (-) terminal.


SULPHATED BATTERY

Many lightly sulphated batteries can be returned to good condition by slow charging.

The rate of charge for a sulphated battery should be no more than half of the normal slow charge rate and the charging time should be from 60 to 100 hours. This long charging cycle is necessary to reconvert crystalline lead sulphate into active materials.

DRY-CHARGED BATTERY

Generally, a dry-charged battery can be used simply by pouring in electrolyte, without recharging it, provided it is stored for a short period in good condition. In consideration of the storage period and storage condition, however, the battery should be recharged by the method described as follows before use.





BATTERY / FUSES

Remove the seals.

Caution

Be sure not to open the seal until electrolyte is poured in for use.

Pour in electrolyte of the same specific gravity as the fully charged battery and leave it for an hour. Recharge the battery for about 10 hours at 10-hour charging rate.

NOTE

A battery stored with its seal in incomplete stored over a long period should be recharged for a longer time.

INSPECTION

- (1) Check for fluid leakage.
- (2) Check the battery casing for deformation or cracks.
- (3) Check the terminals for corrosion.
- (4) Check specific gravity of the electrolyte.
- (5) Check fluid level.
- (6) Check the cap for clogging or looseness.

FUSES

SPECIFICATIONS

Fuse A Colour	5 Tan	10 Red	15 Light blue	20 Yellow
Fusing current A		100)	
Permissible continuous current A		27		
Fusible link size mm ²		Gre- 0.5	en	
Fusible Link Cable colour				

FUSIBLE LINKS


Inspection

Use a circuit tester to check for any blown fusible links.

If a fusible link is blown, it indicates that there is a short or other problem in the live circuit. Be sure to determine the cause and correct it before replacing the fusible link.

Caution

If a fusible link is to be replaced, be sure to use a new fusible link of the specified capacity.



₹ :

FUSES




FUSE BLOCK

inspection

Be sure there is no play in the fuse holders, and that the holders hold the fuses securely. are fuse capacities for each circuit correct? Are there any blown fuses?

Caution

If a fuse is to be replaced, be sure to use a new fuse of the specified capacity.



Fuse Capacity Table


Power supply carcuit	Fuse No	Rated Capacity A	Load circuit	
Battery	1	10	Clock, room lamp, luggage compartment lamp, door warning lamp	
	2	10	Stop lamp	
	3	10	Hazard	
ignition switch	4	15	Wiper motor, washer motor	
IACCI	5	:5	Cigarette lighter, clock, radio	
	6	-		
Ignition switch (IG)	7	.0	Turn-signal lamp, alternator, meter and gauge, indicator and warning lamp, hazard	
	8	10	Back-up lamp	
Battery	9	10	Air-conditioner	
Ignition switch (IG)	10	20	Rear window defogger, heater	
Battery	11	20	Heater	
Battery (through nighting relay)	12	10	Tail lamp, illumination lamp, license plate lamp, position lamp	
Battery	13	10	Horn	


NOTE All equipment other than that listed above is not connected through the fuses, but directly to the battery through relays, switches, etc.

Independent Fuse

UPPER BEAM INDICATOR LAMP FUSE (5A)

This fuse is installed to the R.H. side of engine compartment near the lighting relay.






FUSES / IGNITION SWITCH

AIR-CONDITIONER (15A)

This fuse is installed to the L.H. side of engine compartment near the headlamp.




IGNITION SWITCH

SPECIFICATIONS

ITION SWITCH	
Type	Rotary switch with a steering wheel lock
Load capacity A	TOTAL FOR THE STATE OF THE STAT
AM - ACC	15
AM - 1G 1	12
AM-IC 2	20
AM - ST	
AN-R	15
Voltage grop tupes and the second	15
Voltage grop lunger actual load: V	0 1 or less


COMPONENTS



INSPECTION

Operate the switch, and check the continuity between the terminals.

Terminal Key Position	1	2	3	4	5	6
LOCK						
ACC			6	9		
ON	6	0	0	0		
START	0			0	0	0





SERVICE STANDARD

Fuel gauge indication test When resistance is 3 Ω

Water temperature gauge indication test When resistance is 104 Ω


Water temperature gauge unit operation check When water temperature is 70°C 13

Fuel gauge continuity test Ω Bi-metal type

Water temperature gauge continuity test

Bi-metal type

Fuel gauge



Scale indication A


Scale indication B

104

55

55

Water temperature gauge



68U0144


SPECIFICATIONS


Speedometer			
Speed indication range km/h		0-180	
Indication ratings (range of allowable error)	•		
20 km/h	7-1	+ 4 0	
40 km/h		+4	
80 km/h		+5.5 +0.5	
120 km/h		+75 +15	
Tachometer	•••		•
Туре		Pulse type	
Detection source		Ignition coll 6,000 – 8,000	
Red zone r/min		6.000 - 8.000 NINGE	•
Indication ratings (range of allowable error) r/min		±100	·•
1.000 r/min		±100	,
2,000 r/min		±150	•
3,000 r/min		±200 ·	•
4,000 r/min		±250 ,	
5.000 r/min			



Fuel gauge	
Type *,	Bi-metal type
fuel gauge unit	
Туре	Variable resistance type
Standard resistance value Ω	
Float position "F" point	1 - 5
Float position "E" point	103 - 117
Float vertical movement range mm	117-121
Water temperature gauge	
Type	Bi-metal type
Water temperature gauge unit	
Туре	Thermistor type
Standard resistance value Ω	
70°C	905 - 117.5
115°C	213 - 263

COMPONENTS





REMOVAL

For information regarding the removal of the meter assembly, rafer to GROUP 19.

SPEEDOMETER

Troubleshooting

Symptom	Probable cause	
The speedometer pointer and/or		Remedy
the odometer do not function	Speedometer cable improperly connected Damaged speedometer cable	Correct the routing of the speedometer cable or
	Drive gear is broken	replace the cable
The speedometer pointer moves		Replace the speedometer
off the scale	Oil inside meter Damaged hair spring	
The speedometer pointer will not	Oil inside meter	
eturn to "0", or will not move shove a certain speed	Deformed hair spring Foreign material on the magnet	
The speedometer pointer moves		
erratically	Speedometer cable improperly routed	Correct the routing of the speedometer cable or replace the cable
	Worn induction panel and or bearing	Replace the speedometer
The speedometer functions but the adometer does not	Gear malfunction inside the speedometer	

Inspection

Using a speedometer tester, confirm that the needle remains within the range of allowable error.

Caution

If the front wheels of the vehicle are raised in order to check the speedometer, be sure to chock the rear wheels.

Replacement of the Speedometer Cable


Replace the cable assembly if there is a malfunction.


When connecting the cable to the meter, insert the cable until its stopper properly fits to the meterside groove.

After installing the speedometer, pull the speedometer cable through the grommet in the toeboard until the cable marking is visible from the engine compartment side.

Caution

Poor installation of the cable may cause a fluctuating meter pointer, or noise and a damaged harness inside the instrument panel.





6 1 1



TACHOMETER

Inspection

Connect a Tacho-dwell meter, and then compare the meter readings at various engine speeds with the values indicated on the tachometer. If there is a large error, replace the tachometer.


Caution


The tachometer is the negative-earth type, and therefore should not be connected in reverse to the battery. If the tachometer is connected in reverse, transistors and diodes will be damaged.

FUEL GAUGE AND UNIT

Troubleshooting

- 1. Indication needle does not move
- 2. Incorrect indication






Inspection

FUEL GAUGE INDICATION TEST

Disconnect the wiring connector from the fuel gauge unit inside the luggage compartment. Connect a resistance between the terminals and confirm the gauge indications.




FUEL GAUGE CONTINUITY TEST

Measure the resistance between the terminals by using a circuit tester.

NOTE

If the resistance value is extremely low, there may be a short in the coil; if it is extremely high, there may be a broken wire or some other problem in the coil.





MARILIAN

WATER TEMPERATURE GAUGE AND UNIT

Troubleshooting

Indication needle does not move Incorrect indication






Inspection

WATER TEMPERATURE GAUGE INDICATION TEST

Disconnect the wiring connector from the water temperature gauge unit inside the engine compartment.

Connect a resistance to the connector, and then confirm the gauge indications.




WATER TEMPERATURE GAUGE CONTINUITY
TEST

Measure the resistance between the terminals by using a circuit tester.


NOTE

If the resistance value is extremely low, there may be a short in the coil; if it is extremely high, there may be a broken wire or some other problem in the coil.




WATER TEMPERATURE GAUGE UNIT OPERA-TION CHECK

Measure the resistance with the gauge unit in hot water at 70°C.




MARIZALA. I. ADD DL RAHMI



SPECIFICATIONS

Ind	icator lamp W		•
1.	Fuel warning lamp	3.4	
2.	Brake warning lamp	1.4	
3.	Charging warning lamp	1.4	
4	Turn-signal indicator lamp	1 4	
5	Upper-beam indicator lamp	1.4	
6.	Door-ajar warning lamp	1.4	
7	Oil pressure warning lamp	1.4	




Parking brake switch		
Rated load W		5
Voltage drop (at 12V and the rated load)	V	0.1 or less
Brake fluid level sensor		
Rated load W		3.6
Voltage drop lat 12V and the rated load)	V	0 1 or less
Door switch		
Rated load W		15
Voltage drop (at 12V and the rated load)	· ·	0.2 or less
Fuel warning sensor	•	
Level of remaining fuel at which the fuel v	varning lamp illuminations lit.	10




TROUBLESHOOTING

Oil Pressure Warning Lamp


Oil pressure warning lamp does not illuminate when engine is started



Oil pressure warning lamp remains illuminated





MARIZANI B. ABOOL RAHIM




Brake Warning Lamp


Brake warning lamp does not illuminate








MARIZANI B. ABOOL RAHIM




Door-ajar Warning Lamp

The door-ajar warning lamp does not illuminate when the door is opened



The door-ajar warning lamp remains illuminated




***** :



Charging Warning Lamp


The charging warning lamp does not go out




MAKIZAM B. ABCITIL RAHIM



The charging warning lamp does not illuminate







Poor connection of the fuel

malfunction in the fuel warning

gauge unit connector, or

sensor

MAKINI IN TO PAHIM

Correct the connection, or

replace the fuel gauge unit



INSPECTION

Fuel Warning Sensor

Connect the gauge unit with a test lamp to the battery, and immerse it in the water.

The lamp should be off while thermistor of the gauge unit is beneath the water, and should illuminate when the unit is taken out of the water.

NOTE


If there is a malfunction, replace the fuel gauge as an assembly.


Caution

After completing this test, wipe the unit dry and install it in the fuel tank.


Brake Fluid Level Sensor

The sensor is considered normal if the warning lamp illuminates when the float is immersed.





LIGHTING SYSTEM



Standard Value		CC
Headlamp intensity		
, , , , , , , , , , , , , , , , , , ,	20,000 or more	
SPECIFICATIONS	-	
Main lamp W		· · · · · · · · · · · · · · · · · · ·
Headlamp		•
Front turn-signal lamp	60/55	
Position lamp	23	•
Side turn-signal lamp	5	
Rear combination lamp	5	•
Turn-signal lamp	22	~
Stop and tail lamp	23	•
Back-up lamp	21/5	L
License plate lamp	23 6	-
Sub lamp W		<u> </u>
Room tamp	10	
Luggage compartment lamp	5	
Combination meter illumination lamp	3.4	
Cigarette lighter illumination lamp	1 4	
Heater panel illumination lamp	1.4	
4shtray illumination amp	1 4	
Top mark illumination lamp	5	
Turn-signal and hazard-warning flasher unit		
_vce	Transistor type	
Blinking frequency cycle/min (12.8V, 20°C)		
Turn-signal	85 ± 12	
Hazard-warning	90 ± 12	

MARIZAM B. ABDOL RAHIM



LIGHTING SYSTEM

Column switch	
Lighting switch	
Rated load A	0.17 - 0.27
Position, tail lamp	0.17 - 0.27
Headlamp	0.2 or less
Voltage drop (at 12.8V and the rated load) V	
Turn-signal switch	6.1 - 7.1
Rated load A	0.2 or less
Voltage drop (at 12V and the rated load) V	
Dimmer switch	
Rated load A	16.1 - 18.7
Upper beam	9.4 - 10.8
Lower beam	0.2 or less
Voltage drop (at 12V and the rated load) V	
Passing switch	16.1 — 18.7
Rated load A	0.2 or less
Voltage drop (at 12V and the rated load) V	
Hazard-warning switch	Push-lock type
Type	10
Rated load A	0 1 or less
Voltage drop: V lat 12V and the rated load	U I UI ICSO
headiams relay and tall lamb relay	
Exciting coil rated current A	0.074 — 0 106
Maximum contact current capacity A	20
Frange of voltage usec V	10 – 15
Voltage drop betweer, terminals V	0.2 or less
Rheostat	
Type	Variable resistance type
Resistance Ω	$0-10+\frac{1.0}{-2.0}$
Rated load W	Max. 28
Voltage drop (at 14V and the rated load) V	0.15 or less


LIGHTING SYSTEM




 $\Gamma >$

COMPONENTS

Headlamp




Side turn-signal lamp




1600336


Position lamp



Front turn-signal lamp




Top illumination lamp




License plate lamp

1600338


Rear combination lamp




- MARIZAM B. ABOOL RAHIM



Room lamp




Rheostat




Luggage compartment lamp


1600337



Hazard-warning switch



Column switch



1600307



TROUBLESHOOTING

Check the lamps for illumination to determine the reason for failure and check as applicable for each reason for failure. (For trouble symptom Nos 3 and 4 refer to the yes/no troubleshooting chart.)


Location	Trouble-symptoms						
				Airibrou	 \$		
Headlamps Forbiels and make in	<u> </u>	2	3	4	5,	8	7
Soth left and right lamps illuminate in upper and lower	×	0	×	0	Δ		
Sazina jamba						0	
Both left and right lamps illuminate in upper beams when the cassing switch is at ON position]	0	×	×	0	0	^	
Position, fail and license plate lamps	ļ					Δ	
All lamps illuminate with the lighting switch in the first	0	0	0	×	0	0	
Probable cause	 						
Headlamp relay	1	1		ļ	i		
Tail lamp relay	•	_	•		_		•
	_	_	_	•			
Column switch [Dimmer switch segment]	•		•				
[Passing switch segment]						_	•
[Lighting switch segment]			-			•	•
	•	_	•	•	•	_	•
Body earth point [Headlamp support and cowl side]	•		•	•	_		•
[Luggage compartment]					<u> </u>	<u> </u>	
Fuse block		 	-				
[No. 12 fuse]	-	_	-	•	-	_	-
Lamp bulb	_		-			 	-

Remarks

The symbols used in the table indicate the following:


- O Normal illumination
- △ Dim illumination
- × No illumination
- Parts requiring check


MARILATIN B. ABOOL RALINA



Trouble Symptom 3


Left and right passing lamps and headlamp upper and lower beams do not illuminate






Trouble Symptom 4

The left and right position, tail, and license plate lamps do not illuminate




MARIEN 3. ACIDICAL PROPERTY OF THE PARTY OF




Turn-signal Lamp

The blinking of the turn-signal lamps is irregular




One of the turn-signal or indicator lamps does not illuminate





None of the turn-signal and indicator lamps illuminate





MARIZAN B. ABOUL FAHIM



Hazard Lamps

None of the hazard lamps and indicator lamps illuminate.





HEADLAMPS

Aiming

The headlamps should be aimed with the proper beam-setting equipment, and in accordance with the equipment manufacturer's instructions.

NOTE


If there are any regulations pertinent to the arming of headlamps in the area where the vehicle is to be used, adjust so as to meet those requirements.


Alternately turn the adjusting bolts to adjust the headlamp aiming.


If beam-setting equipment is not available, proceed as follows:

- (1) Inflate the tires to the specified pressures and remove the load from the vehicle (except a driver).
- Draw vertical lines (vertical lines passing through respective headlamp centres) and a horizontal line (horizontal line passing through centre of headlamps) on the screen.
- (3) With the engine running at 2,000 r/min, aim the headlamps.

Make the vertical and horizontal adjustment of the upper beam to the standard values by using the adjusting bolts.









Intensity Measurement

The headlamp intensity should be tested with the engine running at 2,000 r/min and while the battery is charging.

For a screen-type test, place the screen 3 m away from the headlamps.

For a focusing type test, the distance from the headlamps to the light receiving area should be 1m.

Receiver - 3 m : Screen type - 1 m : Focusing type Level floor

Replacement of Replaceable Bulb

- (1) Disconnect the negative (-) cable from the battery.
- Disconnect the headlamp harness connector.
- (3) Detach the socket cover from the back of the headlamp.
- (4) Detach the socket holder, and then take out the bulb and socket assembly.

Caution

Never touch the glass surface of the headlamp bulb with a bare hand or with dirty gloves.

If the glass surface is dirty, he sure to all and it.


If the glass surface is dirty, be sure to clean it with alcohol, paint thinner, etc., and install it after drying it thoroughly.




Remove the radiator grille. (Refer to GROUP 18.)
Remove the position lamp.

Flemove the headlamp unit attaching nuts and boits and connector from inside the engine compartment

Remove the headlamp unit.







COLUMN SWITCH

Removal

Remove the steering wheel. (Refer to GROUP 13A.)

Remove the column cover. (Refer to GROUP 19.)
Remove the connector of the column switch and remove the column switch attaching screws.





Turn signal switch

inspection

Operate the switch, and check the continuity be-

LIGHTING SWITCH

	Terminal			
Switch position		1	2	8
OFF				
1		6		
2		0		
Control of the last of the las				[0

TURN-SIGNAL SWITCH

	Terminal			
Switch Dosition		3	5	4 '
L		6		
N				
R		0	0	

DIMMER-PASSING SWITCH

Switch position	9	7	6	2
Ο,	<u></u>			
D2	<u>></u>		-o	
P	0		<u> </u>	0

Installation

With the canceling cam projection directed to the right, install the steering wheel.

Lane change (automatic reset) N Proposition of the second of the secon


HAZARD-WARNING SWITCH


Removal

Use a special tool to remove the switch.

Caution

Use care not to damage the meter hood.






Inspection

Operate the switch, and check the continuity between the terminals.

Terminal Switch position	1	2	3	4	5	6
OEE		b	ρ			
ON	P		ρ	b	b	ρ



HEADLAMP RELAY AND TAIL LAMP RELAY

Inspection

Check for continuity between the terminals while power is being supplied and while it is not.

While power is not supplied:


Between terminals 1 – 2:

no continuity

Between terminals 3-4: continuity

While power is supplied:

Between terminals 1 – 2: continuity




RHEOSTAT


Inspection

With the connector disconnected, measure the continuity between the rheostat terminals with an ohimmeter or a circuit tester.

If the resistance value varies smoothly between 0 and 10 onms throughout the entire operation range, the rheostat is normal.



WINDSHIELD WIPERS AND WASHER



SERVICE STANDARD


Standard Value		
Wiper blade stopping position (distance between blade tip and Driver's side		ww
Driver's side		
Front passenger's side		
	15	
TIGHTENING TORQUE	20	
Wiper pivot shaft installing nut		kgm
Wiper arm locking nut	0.6 - 0.8	
	1.0 - 1.6	
SPECIFICATIONS		

Wiper motor	
Type	
Speed control system	Permanent-magnet type
Braking system	Third brush system
r/min at load of 0.1 kgm r/min	Dynamic brake system
Low speed	
High speed	44 - 52
Nominal torque kgm	63 – 77
Wiper blade	1.8
Wiping angle	
Driver's side	
Passenger's side	79.5° ± 2°
Wiper blade length mm	93° ± 2°
Driver's side	480
Passenger's side	450 450
Vindow washer motor and pump	, 430
Motor type	Direct current ferrite magnet type
^p ump type	Centrifugal type
Power consumption A	3.5 or less
Time of continuous use sec.	
With washer fluid	Max. 60
Empty operation	Max. 20
Nozzie jet pressure – kg/cm²	08 or more
Tank capacity lit.	2.3 or more
Niper and washer switch	
Rated load W	
Wiper switch	60 <u>Contraction of the contraction of the contracti</u>
Washer switch	40
Voltage drop (at 12V and the rated load)	0.2 or less
ntermittent wiper control unit	0.2 or less MARILLAND
Intermittent cycle sec.	3-0
Delay time during washer operation sec.	0.4 — 1.2
Operating load W	60




WINDSHIELD WIPERS AND WASHER


COMPONENTS



1600316



16U0189



1600160

Remarks For the installed position of intermittent wiper relay, refer to P 16-18